

INGEO BIOPOLYMER 3D700

For Large-Format Additive Manufacturing

DESCRIPTION

Ingeo 3D700 has been specifically developed for use in large-format printers (e.g.- medium to big-area machines), to minimize the chance of failed prints due to part-warpage and excessive material shrinkage.

Ingeo 3D700 is supplied as pellets that can be directly printed using fused granulate fabrication (FGF) systems, or can also be first converted to filament, for use in fused filament fabrication (FFF) platforms.

This grade is also amenable to formulating with additives (e.g.- process aids, reinforcing-agents, impact modifiers), to customize performance for specific end-use applications.

PROCESSING INFORMATION

Due to the variety of printer-platforms in the market, the table below only contains general ranges in which Ingeo 3D700 may be processed. Conditions may need to be optimized for specific printers. Drying, prior to melt extrusion is essential to ensure quality consistency. Ingeo 3D700 is an amorphous grade and could become tacky at temperatures greater than 45 °C. Therefore, it is important to minimize temperature spikes and prevent hot-spots in the dryer.

Screw-cooling in the feed section may be necessary in some cases, to prevent resin from sticking to screw. Please contact NatureWorks if related technical support is necessary.

DRYING

In-line drying is required. A moisture content of less than 0.025% (250 ppm) is recommended to prevent viscosity degradation. Typical drying conditions are 6-8 hours at 113°F (45 °C) or to a dew point of -30 °F (-35 °C), with an airflow rate greater than 0.5 cfm/lb of resin throughput.

BULK MECHANICAL PROPERTIES*

Tensile Modulus	474 kpsi	ASTM D638
Tensile strength	6.9 kpsi	ASTM D638
Flexural strength	14.8 kpsi	ASTM D790
Flexural Modulus	531.5 kpsi	ASTM D790
Linear shrink	0.34%	

**Typical properties measured on injection molded bars; not to be construed as specifications or properties of 3D printed part.*

PHYSICAL PROPERTIES

MFR, g/10 min (210°C, 2.16kg)	9-12	ASTM D1238 (adapted to include best practices to dry Ingeo)
Density	1.24 g/cc	ASTM D1505
Glass transition temperature	55-60 °C	ASTM D3418
Pellet Clarity	>90%	ASTM D1003

PROCESS TEMPERATURE PROFILE

Feed Throat	25-30 °C
Extruder Zone1	150-170 °C
Compression section	180-190 °C
Metering section	180-190 °C
Die	190-200 °C
Print bed	40-50 °C, if needed

BULK STORAGE RECOMMENDATIONS

The resin silos recommended and used by NatureWorks are designed to maintain dry air in the silo and to be isolated from the outside air. This design would be in contrast to an open, vented to atmosphere common when processing polystyrene. Key features that are added to a typical (example: polystyrene) resin silo to achieve this objective include a cyclone and rotary valve loading system and some pressure vessel relief valves. The dry air supply to the system is sized in proportion to the resin flow rate through the silo. Often, the necessary flow of dry air is minimal and there may be excess instrument air (-30°F dew point) available in the plant to meet the needs for dry air supply. Our estimate is 10 scfm for a 20,000 lb/hr rate resin usage. Typically, resin manufacturers specify aluminum or stainless steel silos for the resin manufacturing operation and avoid epoxy-lined steel.

SAFETY AND HANDLING CONSIDERATIONS

Safety Data Sheets (SDS) for Ingeo biopolymers are available from NatureWorks. SDS's are provided to help customers satisfy their own handling, safety, and disposal needs, and those that may be required by locally applicable health and safety regulations. SDS's are updated regularly; therefore, please request and review the most current SDS's before handling or using any product. The following comments apply only to Ingeo biopolymers; additives and processing aids used in fabrication and other materials used in finishing steps have their own safe-use profile and must be investigated separately.

HAZARDS AND HANDLING PRECAUTIONS

Ingeo biopolymers have a very low degree of toxicity and, under normal conditions of use, should pose no unusual problems from incidental ingestion or eye and skin contact. However, caution is advised when handling, storing, using, or disposing of these resins, and good housekeeping and controlling of dusts are necessary for safe handling of product. Pellets or beads may present a slipping hazard. No other precautions other than clean, body-covering clothing should be needed for handling Ingeo biopolymers. Use gloves with insulation for thermal protection when exposure to the melt is localized. Workers should be protected from the possibility of contact with molten resin during fabrication. Handling and fabrication of resins can result in the generation of vapors and dusts that may cause irritation to eyes and the upper respiratory tract. In dusty atmospheres, use an approved dust respirator. Good general ventilation of the polymer processing area is recommended. At temperatures exceeding the polymer melt temperature (typically 175 °C), polymer can release fumes, which may contain fragments of the polymer, creating a potential to irritate eyes and mucous membranes. Good general ventilation should be sufficient for most conditions. Local exhaust ventilation is recommended for melt operations. Use safety glasses (or goggles) to prevent exposure to particles, which could cause mechanical injury to the eye. If vapor exposure causes eye discomfort, improve localized fume exhausting methods or use a fullface respirator. The primary thermal decomposition product of PLA is acetaldehyde, a material also produced during the thermal degradation of PET. Thermal decomposition products also include carbon monoxide and hexanal, all of which exist as gases at normal room conditions. These species are highly flammable, easily ignited by spark or flame, and can also auto ignite. For polyesters such as PLA, thermal decomposition producing flammable vapors containing acetaldehyde and carbon monoxide can occur in almost any process equipment maintaining PLA at high temperature over longer residence times than typically experienced in extruders, fiber spinning lines, injection molding machines, accumulators, pipe lines and adapters. As a rough guideline based upon some practical experience, significant decomposition of PLA will occur if polymer residues are held at temperatures above the melting point for prolonged periods, e.g., in excess of 24 hours at 175°C, although this will vary significantly with temperature.

COMBUSTIBILITY

Ingeo biopolymers will burn. Clear to white smoke is produced when product burns. Toxic fumes are released under conditions of incomplete combustion. Do not permit dust to accumulate. Dust layers can be ignited by spontaneous combustion or other ignition sources. When suspended in air, dust can pose an explosion hazard. Firefighters should wear positive-pressure, self-contained breathing apparatuses and full protective equipment. Water or water fog is the preferred extinguishing medium. Foam, alcohol-resistant foam, carbon dioxide or dry chemicals may also be used. Soak thoroughly with water to cool and prevent re-ignition.

DISPOSAL

DO NOT DUMP INTO ANY SEWERS, ON THE GROUND, OR INTO ANY BODY OF WATER. For unused or uncontaminated material, the preferred option is to recycle into the process; otherwise, send to an incinerator or other thermal destruction device. For used or contaminated material, the disposal options remain the same, although additional evaluation is required. Disposal must be in compliance with Federal, State/Provincial, and local laws and regulations.

ENVIRONMENTAL CONCERNS

Generally speaking, lost pellets, while undesirable, are benign in terms of their physical environmental impact, but if ingested by wildlife, they may mechanically cause adverse effects. Spills should be minimized, and they should be cleaned up when they happen. Plastics should not be discarded into the environment.

PRODUCT STEWARDSHIP

NatureWorks has a fundamental duty to all those that use our products, and for the environment in which we live. This duty is the basis for our Product Stewardship philosophy, by which we assess the health and environmental information on our products and their intended use, and then take appropriate steps to protect the environment and the health of our employees and the public.

CUSTOMER NOTICE

NatureWorks encourages its customers and potential users of its products to review their applications from the standpoint of human health and environmental quality. To help ensure our products are not used in ways for which they were not intended or tested, our personnel will assist customers in dealing with ecological and product safety considerations. Your sales representative can arrange the proper contacts. NatureWorks literature should be consulted prior to the use of the company's products.

NOTICE

No freedom from infringement of any patent owned by NatureWorks LLC or others is to be inferred. No information in this publication can be considered a suggestion to infringe patents.

The technical information, recommendations and other statements contained in this document are based upon tests or experience that NatureWorks believes are reliable, but the accuracy or completeness of such information is not guaranteed. Many factors beyond NatureWorks control can affect the use and performance of a NatureWorks product in a particular application, including the conditions under which the product is used and the time and environmental conditions in which the product is expected to perform. Since these factors are uniquely within the user's knowledge or control, it is essential that the user evaluate the NatureWorks product to determine whether it is fit for a particular purpose and suitable for the user's method of application. In addition, because use conditions are outside of NatureWorks control and applicable laws may differ from one location to another and may change with time, Customer is solely responsible for determining whether products and the information in this document are appropriate for Customer's use and for ensuring that Customer's workplace, use and disposal practices are in compliance with applicable laws and regulations. NatureWorks LLC assumes no obligation or liability for the information in this document.

NATUREWORKS MAKES NO WARRANTY, EXPRESS OR IMPLIED, REGARDING THE INFORMATION CONTAINED HEREIN OR ITS PRODUCTS, INCLUDING BUT NOT LIMITED TO ANY WARRANTY AS TO ACCURACY OR COMPLETENESS OF INFORMATION, OR ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

WARNING REGARDING MEDICAL APPLICATIONS

NatureWorks products are not designed or manufactured for medical applications (“Medical Applications”), including without limitation, any commercial or developmental applications intended:

- (a) For implantation in the human body or contact with human internal body fluids or body tissues, regardless of the length of time involved;
- (b) As a critical component of any medical device that supports or sustains human life; or
- (c) For use specifically by pregnant women or in any applications designed specifically to promote or interfere with human reproduction.

NATUREWORKS MAKES NO REPRESENTATION, PROMISE, EXPRESS WARRANTY OR IMPLIED WARRANTY THAT NATUREWORKS PRODUCTS ARE BIO-COMPATIBLE OR OTHERWISE FIT FOR MEDICAL APPLICATIONS. DO NOT USE NATUREWORKS PRODUCTS FOR MEDICAL APPLICATIONS unless the products have been provided from NatureWorks under a written contract that expressly approves the contemplated use. NatureWorks has no specific expertise in Medical Applications and does not perform testing, clinical studies or investigations of the suitability of its products for specific Medical Applications. Do not rely on NatureWorks to determine if a NatureWorks product is suitable for a Medical Application. Any customer or downstream user of NatureWorks Products is solely responsible for determining whether the product is safe, lawful and technically suitable for its intended use, and for conducting their own studies, registrations and other activities to establish the safety, regulatory compliance and efficacy of their products.

NOTICE REGARDING PROHIBITED USE RESTRICTIONS: Unless specifically agreed to in writing by NatureWorks, NatureWorks LLC will not knowingly sell or sample any product into any of the following commercial or developmental applications (i) components of or packaging for tobacco products, (ii) components of products intended for human or animal consumption, (iii) any application that is intended for any internal contact with human body fluids or body tissues, (iv) as a critical component in any medical device that supports or sustains human life, (v) in any product that is designed specifically for ingestion or internal use by pregnant women, (vi) in any application designed specifically to promote or interfere with human reproduction, (vii) in microbeads, including those used in personal care/cosmetic applications, or (viii) to manufacture bottles or bottle pre-forms in North America.



15305 Minnetonka Blvd., Minnetonka, MN 55345

For additional information please contact NatureWorks via our [website](#) or reach out to us from our [Contact Us Page](#)