

# Ingeo™ Biopolymer 6260D Technical Data Sheet

## Melt Blown Fiber and Fiber Melt Spinning

Ingeo biopolymer 6260D, a NatureWorks product, is a thermoplastic fiber-grade resin derived primarily from annually renewable resources. Available in pellet form, 6260D is designed for melt blown fiber processing or extrusion into mechanically drawn staple fibers, using conventional fiber spinning and drawing equipment. 6260D is well suited for fiber processes where low boiling water fiber shrinkage and higher dimensional stability is required, in addition to low extrusion pressure. Ingeo biopolymer 6260D can be converted into a broad range of fiber products. See table for typical properties.

### Applications

Potential applications for Ingeo biopolymer 6260D include:

- Melt blown fiber
- Staple fiber
- Nonwovens
- Agricultural woven and nonwoven fabrics
- Articles for household disposal
- Textiles
- Spunbond fabrics

### Processing Information

Ingeo biopolymer 6260D will process on conventional melt blown, and extrusion spinning and drawing equipment. Thorough cleaning is required because PLA is not compatible with a wide variety of polymers.

### Machine Configuration

General-purpose screws with L/D ratios of 24:1 to 30:1 and 3:1 compression ratios are recommended. However, screws with mixing sections or shallow metering channels may overheat the melt at high screw speeds. Typical process temperatures are 220-250°C. Like PET, Ingeo 6260D requires either high filament velocity or drawing and controlled heat setting to control shrinkage in spun bond and staple processes. Melt blown processes can be controlled for low shrinkage by minimizing orientation using conventional process parameters.

### Drying

In-line drying capabilities are essential to process Ingeo biopolymer 6260D, which is supplied with moisture content

Typical Material & Application Properties <sup>(1)</sup>		
Physical Properties	Ingeo 6100D	ASTM Method
Specific Gravity (g/cm <sup>3</sup> )	1.24	D792
Relative Viscosity <sup>(2)</sup>	2.5	D5225
Melt Index (g/10 min at 210°C)	65	D1238
Melt Density (g/cm <sup>3</sup> at 230°C)	1.08	
Glass Transition Temperature (°C)	55-60	D3417
Crystalline Melt Temperature (°C)	165-180	D3418
Typical Fiber Properties <sup>(3)</sup>		
Denier per Filament (g/9000m)	≥0.5 dpf	
Tenacity (g/d)	2.0-4.0	D2256/D3822
Elongation (%)	10-70	D2256/D3822
Modulus (g/d)	30-55	D2256/D3822
Boiling Water Shrinkage (%)	3-4	D2102
Hot Air Shrinkage (% at 130°C, 10 min)	4-5	D2102

(1) Typical properties; not to be construed as specifications.

(2) RV measured at 1.0 g/dL in chloroform at 30°C

(3) Spun at 225°C melt temp. at 1500 mpm, drawn 2.7x at 95°C, heat set at 150°C

of less than 0.040% (400 ppm). The recommended moisture content to prevent viscosity degradation and potential loss of properties is less than 0.005% (50 ppm). Typical drying conditions are 4-6 hours at 80°C [176°F] at a dew point of – 35°C [-30°F] or lower, with an airflow rate of greater than 0.5 cfm/lbs per hour of resin throughput. To prevent moisture regain, the resin should not be exposed to atmospheric conditions after drying.

### Food Packaging Status

#### U.S. Status

On January 3, 2002 FCN 000178 submitted by NatureWorks LLC to FDA became effective. This effective notification is part of list currently maintained on FDA's website at

<http://www.fda.gov/Food/FoodIngredientsPackaging/FoodContactSubstancesFCS/ucm116567.htm>

This grade of Ingeo biopolymer may therefore be used in food packaging materials and, as such, is a permitted component of such materials pursuant to section 201(s) of the Federal, Drug, and Cosmetic Act, and Parts 182, 184, and 186 of the Food Additive Regulations. All additives and adjuncts contained in the referenced Ingeo biopolymer formulation meet the applicable sections of the Federal Food, Drug, and Cosmetic Act. The finished polymer is approved for all food types and B-H use conditions.

## ***Ingeo Biopolymer 6260D Technical Data Sheet***

Migration testing for this product was done using rolled sheet with an approximate thickness of 0.020 inches. Depending on the application, the surface area of a fiber article may differ from the sheet sample tested. It is therefore the responsibility of the manufacturer of the finished food-contact article to determine that the use of a product is safe, lawful, and technically suitable for the intended application. We urge all of our customers to perform GMP (Good Manufacturing Procedures) when constructing a package so that it is suitable for the end use.

### **European Status**

This grade of Ingeo biopolymer complies with Plastics Regulation 10/2011 as amended. No SML's for the above referenced grade exist in Plastics Regulation 10/2011 as amended. NatureWorks LLC would like to draw your attention to the fact that the EU- Plastics Regulation 10/2011, which applies to all EU-Member States, includes a limit of 10 mg/dm<sup>2</sup> of the overall migration from finished plastic articles into food. In accordance with Plastics Regulation 10/2011 the migration should be measured on finished articles placed into contact with the foodstuff or appropriate food simulants for a period and at a temperature which are chosen by reference to the contact conditions in actual use, according to the rules laid down in Plastics Regulation 10/2011. OML testing for this product was done using rolled sheet. Depending on the application, the surface area of a fiber article may differ from the sheet sample tested.

Please note that it is the responsibility of both the manufacturers of finished food contact articles as well as the industrial food packers to make sure that these articles in their actual use are in compliance with the imposed specific and overall migration requirements.

This grade as supplied meets European Parliament and Council Directive 94/62/EC of 20 December 1994 on packaging and packaging waste heavy metal content as described in Article 11.

Should you need further clarification, contact NatureWorks LLC.

## **Bulk Storage Recommendations**

---

The resin silos recommended and used by NatureWorks LLC are designed to maintain dry air in the silo and to be isolated from the outside air. This design would be in contrast to an open, vented to atmosphere system that we understand to be a typical polystyrene resin silo. Key features that are added to a typical (example: polystyrene) resin silo to achieve this objective include a cyclone and rotary valve loading system and some pressure vessel relief valves. The dry air put to the system is sized to the resin flow rate out of the silo. Not too much dry air would be needed and there may be excess instrument air (-30°F dew point) available in the plant to meet the needs for dry air. Our estimate is 10 scfm for a 20,000 lb/hr rate resin usage. Typically, resin manufacturers specify aluminum or stainless steel silos for their own use and avoid epoxy-lined steel.

### Safety and Handling Considerations

---

Safety Data Sheets (SDS) for Ingeo biopolymers are available from NatureWorks. SDS's are provided to help customers satisfy their own handling, safety, and disposal needs, and those that may be required by locally applicable health and safety regulations. SDS's are updated regularly; therefore, please request and review the most current SDS's before handling or using any product.

*The following comments apply only to Ingeo biopolymers; additives and processing aids used in fabrication and other materials used in finishing steps have their own safe-use profile and must be investigated separately.*

### Hazards and Handling Precautions

---

Ingeo biopolymers have a very low degree of toxicity and, under normal conditions of use, should pose no unusual problems from incidental ingestion or eye and skin contact. However, caution is advised when handling, storing, using, or disposing of these resins, and good housekeeping and controlling of dusts are necessary for safe handling of product. Pellets or beads may present a slipping hazard.

No other precautions other than clean, body-covering clothing should be needed for handling Ingeo biopolymers. Use gloves with insulation for thermal protection when exposure to the melt is localized. Workers should be protected from the possibility of contact with molten resin during fabrication.

Handling and fabrication of resins can result in the generation of vapors and dusts that may cause irritation to eyes and the upper respiratory tract. In dusty atmospheres, use an approved dust respirator.

Good general ventilation of the polymer processing area is recommended. At temperatures exceeding the polymer melt temperature (typically 175°C), polymer can release fumes, which may contain fragments of the polymer, creating a potential to irritate eyes and mucous membranes. Good general ventilation should be sufficient for most conditions. Local exhaust ventilation is recommended for melt operations. Use safety glasses (or goggles) to prevent exposure to particles, which could cause mechanical injury to the eye. If vapor exposure causes eye discomfort, improve localized fume exhausting methods or use a full-face respirator.

The primary thermal decomposition product of PLA is acetaldehyde, a material also produced during the thermal degradation of PET. Thermal decomposition products also include carbon monoxide and hexanal, all of which exist as gases at normal room conditions. These species are highly flammable, easily ignited by spark or flame, and can also

auto ignite. For polyesters such as PLA, thermal decomposition producing flammable vapors containing acetaldehyde and carbon monoxide can occur in almost any process equipment maintaining PLA at high temperature over longer residence times than typically experienced in extruders, fiber spinning lines, injection molding machines, accumulators, pipe lines and adapters. As a rough guideline based upon some practical experience, significant decomposition of PLA will occur if polymer residues are held at temperatures above the melting point for prolonged periods, e.g., in excess of 24 hours at 175°C, although this will vary significantly with temperature.

### Combustibility

---

Ingeo biopolymers will burn. Clear to white smoke is produced when product burns. Toxic fumes are released under conditions of incomplete combustion. Do not permit dust to accumulate. Dust layers can be ignited by spontaneous combustion or other ignition sources. When suspended in air, dust can pose an explosion hazard. Firefighters should wear positive-pressure, self-contained breathing apparatuses and full protective equipment. Water or water fog is the preferred extinguishing medium. Foam, alcohol-resistant foam, carbon dioxide or dry chemicals may also be used. Soak thoroughly with water to cool and prevent re-ignition.

### Disposal

---

DO NOT DUMP INTO ANY SEWERS, ON THE GROUND, OR INTO ANY BODY OF WATER. For unused or uncontaminated material, the preferred option is to recycle into the process otherwise, send to an incinerator or other thermal destruction device. For used or contaminated material, the disposal options remain the same, although additional evaluation is required. Disposal must be in compliance with Federal, State/Provincial, and local laws and regulations.

### Environmental Concerns

---

Generally speaking, lost pellets, while undesirable, are benign in terms of their physical environmental impact, but if ingested by wildlife, they may mechanically cause adverse effects. Spills should be minimized, and they should be cleaned up when they happen. Plastics should not be discarded into the environment.

### Product Stewardship

---

NatureWorks has a fundamental duty to all those that use our products, and for the environment in which we live. This duty is the basis for our Product Stewardship philosophy, by which we assess the health and environmental information on our products and their intended use, and then take

## **Ingeo Biopolymer 6260D Technical Data Sheet**

appropriate steps to protect the environment and the health of our employees and the public.

### **Customer Notice**

---

NatureWorks encourages its customers and potential users of its products to review their applications from the

standpoint of human health and environmental quality. To help ensure our products are not used in ways for which they were not intended or tested, our personnel will assist customers in dealing with ecological and product safety considerations. Your sales representative can arrange the proper contacts. NatureWorks literature should be consulted prior to the use of the company's products.

#### **NOTICE:**

No freedom from infringement of any patent owned by NatureWorks LLC or others is to be inferred. No information in this publication can be considered a suggestion to infringe patents.

The technical information, recommendations and other statements contained in this document are based upon tests or experience that NatureWorks believes are reliable, but the accuracy or completeness of such information is not guaranteed. Many factors beyond NatureWorks control can affect the use and performance of a NatureWorks product in a particular application, including the conditions under which the product is used and the time and environmental conditions in which the product is expected to perform. Since these factors are uniquely within the user's knowledge or control, it is essential that the user evaluate the NatureWorks product to determine whether it is fit for a particular purpose and suitable for the user's method of application. In addition, because use conditions are outside of NatureWorks control and applicable laws may differ from one location to another and may change with time, Customer is solely responsible for determining whether products and the information in this document are appropriate for Customer's use and for ensuring that Customer's workplace, use and disposal practices are in compliance with applicable laws and regulations. NatureWorks LLC assumes no obligation or liability for the information in this document.

NATUREWORKS MAKES NO WARRANTY, EXPRESS OR IMPLIED, REGARDING THE INFORMATION CONTAINED HEREIN OR ITS PRODUCTS, INCLUDING BUT NOT LIMITED TO ANY WARRANTY AS TO ACCURACY OR COMPLETENESS OF INFORMATION, OR ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

**NOTICE REGARDING PROHIBITED USE RESTRICTIONS:** Unless specifically agreed to in writing by NatureWorks, NatureWorks LLC will not knowingly sell or sample any product into any of the following commercial or developmental applications (i) components of or packaging for tobacco products, (ii) components of products intended for human or animal consumption, (iii) any application that is intended for any internal contact with human body fluids or body tissues, (iv) as a critical component in any medical device that supports or sustains human life, (v) in any product that is designed specifically for ingestion or internal use by pregnant women, (vi) in any application designed specifically to promote or interfere with human reproduction, (vii) in microbeads, including those used in personal care/cosmetic applications, or (viii) to manufacture bottles or bottle pre-forms in North America.

For additional information please contact NatureWorks via our [website](#) on the tab called [FAQ's](#) or by clicking [here](#).



15305 Minnetonka Blvd., Minnetonka, MN 55345